

操作使用说明书

声明

- 你的手机授权使用GSM网络系统并符合以下指标:
- ETS300-342-1欧洲数字通信系统的“电磁兼容”(简称EMC)
- 98/13/EC、CTR19和CTR20(CTR指通用工业技术指标)
- 73/23/EEC“低电压指标”改良为93/68/EEC

技术规格

重量: 111克(含电池)

尺寸: 115mm(高) x 60.5mm(宽) x 11.5(厚)

标准电池: 锂电池3.7V 1800mAh

待机时间: 160-280小时

通话时间: 210-300分钟

屏幕: 手写TFTLCD240 x 320像素

频道: 4频段: GSM850、GSM900、DCS1800、PCS1900MHz

待机时间和通话时间需视手机使用实际情况及网络服务状况而定如何安装SIM卡。

进行下列步骤时,请确保手机的电源已经关闭,并在没有充电的情况下,本手机可安装2张SIM卡,也仅可使用1张SIM卡(可在模式设置进行选择,上部插槽是SIM卡1插槽、底部插槽是SIM卡2插槽)。取下电池盖和电池,把第一张SIM卡放入底部的SIM卡2插槽内,注意使SIM卡的金属触点面朝上,SIM卡的缺角在右上角,如果需要,将第二张SIM卡放入上部的SIM卡插槽内,注意使SIM卡的金属触点面朝下,SIM卡的缺角在左上角。

1

JAVA

通过JAVA技术,你的手机具备了无限的可扩展性,具有准智能机的特色,你可以自己安装JAVA软件,如各种办公软件与游戏,你也可以登入我们的技术支持网站下载,并不是所有的JAVA软件都可以在本机运行,请注意某些JAVA软件可能在安装或运行中导致系统死机, JAVA软件在运行时可能会占用大量的系统内存,请下载JAVA软件到TF卡的JAVA目录中,然后通过文件管理找到你需要安装的JAVA软件,点击安装,系统将自动进行安装,选

择安装目录到TF卡,知道安装完毕,打开JAVA菜单,进入已安装的JAVA程序目录,即可以找到你已经安装的JAVA软件,点击之后即可运行。

备注:了解JAVA的更多信息。

游戏:本手机内置智能魔法寿司游戏,根据自己的喜好选择在游戏中是否开启音效和振动,功能,进入后用左右方向键选择开启或关闭,更多的游戏功能的游戏功能通过JAVA实现。



视频播放器

影音播放器用来播放MP4好3GP格式的视频文件。

只要把符合格式的视频文件拷贝到手机记忆卡中,你就可以带着一个迷你的掌上影院,随时看电影,视频文件要放在记忆卡的video文件夹内,否则,手及将找不到视频文件,点击影音播放器进入文件列表,点想要播放的影片,弹出如下菜单:

播放:开始播放当前影片。

传送:可传送到多种设置中。

更名:更改当前影片名。

删除:删除当前影片。

删除全部档案:一次性删除清单中所有的影片。

排序:可按不同的文件属性进行重新排序,可方便查找。

蓝牙设定:选择是否通过蓝牙设备播放配音。



6

7

备注

SIM 卡保存由你的移动电话、PIN (个人识别码)、PIN2V12 PUK (PIN解锁密码)、PUK2 (PIN2解锁密码) 及网络信息、电话簿数据和SMS (短消息) 数据等, 因此请小心操作SIM卡存放在儿童拿不到的地方。

如何取出SIM卡

关机: 取下电池盖和电池; 用手指向外拨SIM卡, 直接完全取出为止。取下电池前, 请先关机。否则可能会造成存储于SIM卡或手机中的设置或资料丢失。



如何安装电池

按住电池盖并向下滑动, 即可取下电池盖; 先把电池顶部向下放进电池槽内, 然后把电池全部压入电池槽; 合上电池盖。

如何取出电池

长按按功能键, 滑动方向键以关机; 按住电池盖并向下滑动, 取下电池盖, 用力向下按住电池使电池松动后即可取下电池。



2

按键定义

(1) 功能键

此机采用所以功能一键制的形式。待机时按下功能键打开屏幕并且把屏幕下放的方向键右滑动, 直接进入主菜单。菜单操作时, 屏幕最下端的方向键快捷可以执行相应的操作。关机状态, 长按功能键, 直至看到屏幕电量, 显示开机画面为止。开机后, 手机会自动搜寻网络。开机状态长按功能键关机。

(2) 音量键

通话时可调节通话音量。
播放音乐和电影时可调节播放器音量。
可滚动某些菜单栏, 相当于传统手机上下功能。

备注:

如果开机后要求输入PIN码, 键入PIN码并按“确定”功能键。新开户的SIM卡, PIN码由网络运营商提供。如果提示输入话机锁密码, 请输入正确的话机锁密码, 然后按确定功能键即可。



3

视频摄像机

此功能可使你用手机拍摄短片, 操作说明如下:

●	开始录象
	录象中暂存
停止	结束并存录象
← →	数码变焦
▲ ▼	曝光补偿

录象时点按选项键如下菜单:

到播放器: 点按可进入电影播放器清单中查看录象文件。
录象器设定: 对录象器进行多项设置, 用户可用不同的设置组合进行录象, 多试几次, 找到较好的设定组合。
影片设定: 对录象文件进行的各项设置, 用户可根据个人爱好进行选取。
储存路径: 可选手机或记忆卡, 一般应选记忆卡。
还原设定: 如果用户进行了多项上述设定而不满意, 可一次性还原为出厂的设定, 再重新设置/

相册

查看已经拍好的相片:
进入该选项后, 若有相片, 点按选项可进行以下操作:
查看: 放大看该相片。点按上下方向可浏览所有相片。
浏览模式: 你可选择预览多张相片。
传送: 可将该相片传送“至电话簿、至彩信”。
更名: 将该相片名字更改。
删除: 删除本相片。
删除全部档案: 将相簿内全部相片删除。
排序: 将相簿内相片进行排序。



8



9

拨打电话

输入电话号码。若输入号码不正确，按一下清除键，可删除最后输入的一个号码；若清除所以输入号码，按住清除键直到全部号码删除，或点返回键取消。输入正确的号码，然后选择C1(SIM卡1)和C2(SIM卡2)键拨打。如果电话簿中有这个号码，会显示号码的使用者。通话完毕，按一下结束键，屏幕提示通话结束，然后将返菜单模式。



4

短信/写短信

当屏幕出现信息状态图标时，表明你接收到了新的短信信息。若开启接收提示音，则接收到短信手机同时会发出提示音。点屏幕下方的快捷键屏幕出现编辑短信信息窗口，编辑短信信息时，可以点屏幕正下放的标示切换输入法。在编辑过程中，如果输入错误，可以点屏幕右下脚的清除键进行删除操作。



5

照相机

在主菜单点按照相机即可进入。用户用手机屏幕取景，满意后点按屏幕，底部的照相机图标进行拍照。如果设置了快门声，则手机会发出快门声。为了拍得满意的照片，用户除在拍摄时保持平衡外，还要熟悉照相机的各项设置。进入照相机模式后，进入选项，有如下设置项：

- 到相簿：进入手机相册，查看存储在手机中的相片。
- 相机设定：照相机设置，用户可根据自己的偏好进行修改。
- 照片设定：设定照片的大小和品质。
- 白平衡：根据照相时的光源选择不同的设置。
- 情境模式：可选自动或夜拍模式。
- 特效设定：可选择不同的照片特效。
- 相框：只有拍桌布时有效。
- 储存路径：选择相片保存的位置，可选手机或记忆卡。
- 还原设定：如果用户进行了多项设置，觉得不满意，一项一项的修改太麻烦，可用还原设定全部还原，然后重新设定。



10

网络服务

WAP：即WAP浏览器。WAP浏览器需GPRS功能支持。本手机支持GPRS手机上网功能。在你使用上述功能之前，请确认你的SIM卡支持GPRS。

帐号资料：上网前需要确认帐号资料的设置是否正确。
数据帐户：
常用网址：

注：上述各项设置都与SIM卡有关，请咨询你的网络运营商，获取详细的帮助信息。你可在网络运营商的帮助下，完成服务设置。



更多功能的设置

设置功能是只对手机的一些常用功能，如通话设置、话机设置、网络设置、安全设置、恢复出厂设置等功能的设置。这些设置有利于用户更加方便地使用，充分发挥手机的作用。



11

Quick Start Guide

Get support

technical support on network-related services. you may also download free MP3s, MP4, java programs, games and more from this website.

Learn more

to download the user's guide, get answers to frequently asked questions,

© 2008 sciphone inc. All rights reserved.

Sciphone, the sciphone logo are trademarks of sciphone inc., registered in the U. S. and other countries. sciphone is a trademark of sciphone inc. the bluetooth SIG, inc. and any use of such marks by sciphone inc. is under license. 052-9567-A

technology specifications

weight: 111g

dimensions 115mm x 60.5mm x 11.5mm

battery: 1800mah

stand-by time 210-300minute display type: TFT,

QVGADisplay size: 3.2inch, 240 x 320 pixels network:

GSM850/900/1800/1900WHZ

1

JAVA

To date, the java platform has attracted more than 5 million software developers. it's used in every major industry segment and has a presence in a wide range of devices, computers, and networks.

1. download JAVA software from our website or other free websites.

2. copy JAVA software to any folder in the memory card of your sciphone
3. tap documents button and find this JAVA software. tap option button to Install.
4. tap the JAVA button on the home screen, and then you can run install java software.
5. please note that not any JAVA software can run in your sciphone



More song controls

1. copy your favorite Mp3 files to the mp3 folder in the memory card of your sciphone.
2. tap the multimedia button and select audio player to listen mp3 music.
3. tap list button to check music list, and tap option button, more settings will be available.
4. rotate sciphone sideways to automatically change music files,



6



7

Install SIM Card

1. with the back of the phone facing you, remove the battery cover, and place the first SIM card into the bottom SIM card slot with the gold-colored contacts facing upward.
2. if available, place the second SIM card into the top card slot with the gold-colored contacts facing down.



Install the second SIM card



Install the first SIM card

Install battery

align the gold-colored contacts of the battery with the battery compartment contacts. slide the battery into the slot, gold-colored contact side first. when the contacts meet, press the battery into place. Slide and lock the back cover into place.



Power on/power off

1. press and hold the home button for a few seconds to power on
2. slide to unlock the screen; the phone will be in operating mode.
3. press the home button to lock the screen/press the home button again to enter into standby mode
4. press and hold the home button for a few seconds to turn off (slide to power off).
5. press the home button anytime to return to the home screen. even while you're on a call, you can access your message, calendar or other applications.

Volume Up/Down



Home button

Video controls

1. copy your favorite video files to the video folder in the memory card of your sciphone.
2. tap the multimedia button and select video player to watch video files.
3. your sciphone supports Mp4 and 3GP video files only.
4. rotate sciphone to see the video in widescreen, tap your movie to bring up onscreen controls. tap again to hide them.



Viewing photos

1. load your favorite photos onto sciphone from your computer
2. tap the multimedia button and select image viewer to view photos.
3. tap option button, more settings will be available. tap forward button. assign it to a contact.
4. when viewing photos, rotate sciphone to see the photo in widescreen. you may enlarge a photo with onscreen controls.



Make a call

tap the dial button on the home screen, input the phone number and tap call button to make a call manually (sim1 and sim2). you may also make a call in phone book or call history.



4

Write message

tap the SMS button on the home screen to write a text message options, text message, MMS, chat and voice mail service. sciphone supports handwriting recognition with your finger or stylus.



5


Take a picture

1. tap the multimedia button and select camera to take a picture.
2. tap the shot icon on the bottom of the screen, and then you may save or cancel the picture you take.
3. more settings will be available if you tap option button.



Change your settings

tap the settings button on the home screen to turn on airplane mode when flying, change your screen brightness, ring tones or select options for each application, you can check your usage time, and even add a passcode for added security.



Internet service

to access internet service, browse website, just tap the service button and select WAP. please note that you must have GPRS service before using internet service, please contact your provider to make sure if you have GPRS service. and sometimes, you may need to configure your internet service settings yourself. Please visit our website for details.

10

11